

## 8 mm and 8.5 mm Direct-Fit Wire Set Installation Instructions

- Make sure the engine is cool and the ignition is turned off before beginning the ignition wire installation.
- Remove and replace one wire at a time to avoid mixing up the position of the wires on the distributor or routing them to an incorrect spark plug.
- Start with the longest ignition wire first and work your way to the shortest.



1. Apply a small amount of silicon dielectric grease inside the spark plug boot before installing the boot onto the spark plug.
2. Push both the distributor and spark plug ends of the wires firmly into place to ensure a secure connection.
3. Repeat this procedure for all of the ignition wires.

